

**RONNEBY (RNB) AIRPORT S24
COORDINATION PARAMETERS
(ALL TIMES LOCAL)**

Terminal capacity

- 20 minutes departure separation between domestic (Sweden) flights
- 20 minutes arrival separation between domestic (Sweden) flights
- 45 minutes departure separation between Schengen flights
- 60 minutes departure separation between non-Schengen flights

Stands capacity

- Three (3) available stands distributed into
 - (1) stand that can accommodate A/C size S20, ATR, and DH4
 - (2) stands that can accommodate A/C size 737 and 320.
- There can only be one (1) large A/C size 737 and 320 on the apron simultaneously.

RNB AIP airport open hours

- 0500-2400 Monday - Friday
- Closed Saturday
- 0900-2400 Sunday

Requests for departing/arriving movements after/before above times will be forwarded by ACS to airport management for determination of approval.