



# BODØ AIRPORT (BOO)

## Level 2

### Runway Capacity:

Max number of movements per rolling hour:

Arr: 13

Dep: 13

Tot: 25

### Terminal capacity:

Max 2 aircrafts that involve international passenger operations at any time.

Schengen and non-Schengen flights cannot mix.

Minimum 2 hours between Schengen→non-Schengen and vice versa.

### Stands:

Maximum 12 parked passenger aircrafts at any time, whereof maximum 5 parked passenger aircrafts with 110 seats or more at any time.

Flights not in scheduled or charter operation need parking permit from airport operator. See [AIP](#).

### General/Business Aviation:

All visiting GA/BA operators must request airport operator for approval. See [AIP](#).